



*Recommended tools for installation.*



*Apply thinset with a trowel.*



*Place tiles on the thinset. Take extra care to get each tile close together using their interlocking shape.*



*Lightly tap down the tile without pushing the pebble into the thinset.*



*Seal the tile with a good quality penetrating sealer. Color and shine enhancers can also be applied to vary the finish off the pebbles.*



*Apply a sanded grout on 2"x2" sections at a time until the entire installation is covered.*



*When grout has dried for 30 minutes use a stiff bristled brush to remove the excess grout.*



*Repeat sponging off the grout until the desired look is reached. Look for narrow grout lines between pebbles. Once the grout has completely dried seal the tiles a final time.*